

MOSS SUPPLY 7250/7255 PATIO DOOR INSTALLATION INSTRUCTIONS

NEW CONSTRUCTION

READ THESE INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. CHECK ROUGH OPENING SIZE. SIZE SHOULD BE 1/2" LARGER THAN THE DOOR BOTH WIDTH AND HEIGHT.
2. CHECK SILL PLATE – SILL MUST BE LEVEL BEFORE THE DOOR IS SET IN PLACE.
3. CAUTION DOOR IS HEAVY. TAKE APPROPRIATE MEASURES TO PREVENT DAMAGE TO THE DOOR.
4. SET DOOR IN FRONT OF OPENING, THEN REMOVE SHIPPING BRACE.
5. APPLY A CONTINUOUS 3/8" BEAD OF SEALANT TO THE INSIDE OF THE NAILING FIN IN LINE WITH THE NAILING FIN PRE-PUNCHED HOLES.
6. SET DOOR IN THE CENTER OF THE ROUGH OPENING. SHIM DOOR SO THE DOOR FRAME IS LEVEL, SQUARE, AND PLUMB.
7. SECURE THE DOOR INTO THE OPENING. FASTEN THROUGH THE NAILING FIN WITH 1 1/2" SCREWS STARTING AT THE CORNER, THEN EVERY 6" ON CENTER ON ALL FOUR SIDES.
8. CHECK OPERATION OF ACTIVE DOOR PANEL. ADJUST ROLLER WHEEL HEIGHT SO THAT THE PANEL ROLLS SMOOTHLY, MAKE CERTAIN THAT DOOR PANEL LOCKS EASILY.
9. PLACE SHIM BEHIND DOOR KEEPER. INSTALL 2" SCREW THROUGH KEEPER, VINYL DOOR FRAME, SHIM AND INTO FRAME STUD.
10. CHECK SCREEN WHEEL AND KEEPER ADJUSTMENT SO THAT THE SCREEN OPERATES SMOOTHLY.
11. INSULATE THE INSIDE PERIMETER OF THE DOOR FRAME WITH FIBERGLASS INSULATION,
DO NOT USE EXPANDING FOAM INSULATION